



Transitioning the Scenic Railing System to the Century Top Rail System

With the introduction of the New Scenic Rail Less System we have designed the Scenic System to have the ability to be transitioned to the Century System. This can be accomplished by using a Transition Bracket Kit.

The following is a detailed guide to install a railing system that combines the Scenic with the Century System.

Installing the Top Rail bracket onto the Scenic Post

Measure from the top of the post base plate up the post 40" and mark this location.

Place the top rail transition bracket in place with the **bottom of the bracket aligned with the 40" mark**. Taking care to ensure the bracket is centered on the post.

Mark the centre of each of the slotted holes located inside the bracket. Set the bracket aside.

Pre-drill two pilot holes into the post that you have marked, using a 1/16" high speed steel drill bit. Ensure the pilot holes are centered vertically in the slotted holes.

Place the bracket back in place, ensuring the bottom of the bracket is aligned with your mark at the 40" height above the top of the base plate.

Install two # 10 x 3/4" self tapping screw into the pilot holes, do not fully tighten. Check to ensure the bracket is level, centered, straight and at the correct height by ensuring the bottom of the bracket is at your 40" mark. Tighten screws securely

Installing the Bottom Rail bracket onto the Scenic Post

Measure from the top of the post base plate up the post 2" and mark this location. Place the bottom rail transition bracket in place with **the bottom of the bracket aligned with the 2" mark**. Taking extra care to ensure the bracket is centered on the post. Mark the centre of each mounting channel located inside the bracket. Set the bracket aside.

Pre-drill a pilot hole using a 1/16" high speed steel drill bit in the centre of each screw channel at the marks you just made. Place the bracket back in place, ensuring the bottom of the bracket is aligned with your mark at the 2" height above the top of the base plate. Install two #12 x 1-1/2" hex head self tapping screws through the bracket and into the post. Check to ensure the bracket is at correct height and centered. Tighten screws securely.

Install top and bottom rail and begin installing the Century System.

"Scenic Series"- Transition To Century Detail

